


# CRD-2300F/3000F

Wireless Remote Display



**CAS**

## NOTE

- (1) The unauthorized copying of some or all of this manual is prohibited.
- (2) The information contained herein is subject to change without notice.
- (3) If there are any questions such as wrong or missing parts of the contents listed in this manual, please contact us.
- (4) To improve the product performance, functions can be changed with no notice.
- (5) Please understand that CAS does not have responsibility for a demand related to loss, lost profit etc. caused by operating the product, regardless of the third clause.

| WARNING DEFINITIONS   |                                 |
|---|---------------------------------|
|  | This is warning & caution mark  |
|  | This is hazard alert mark       |
|  | This is useful information mark |

# CONTENTS

|   |           |
|---|-----------|
| <b>1. Precautions .....</b>                       | <b>5</b>  |
| <b>2. Main Features.....</b>                      | <b>5</b>  |
| <b>3. Technical Specifications .....</b>          | <b>6</b>  |
| <b>4. Description of Panels and Symbols .....</b> | <b>7</b>  |
| <b>5. Installation.....</b>                       | <b>8</b>  |
| <b>6. General Functions.....</b>                  | <b>11</b> |
| <b>7. Test Mode.....</b>                          | <b>12</b> |
| <b>8. Setting Mode .....</b>                      | <b>13</b> |
| <b>9. Infrared Remote Controller .....</b>        | <b>16</b> |
| <b>10. Wireless Specification.....</b>            | <b>16</b> |
| <b>11. RS-232C Interface.....</b>                 | <b>17</b> |
| <b>12. Real Time Clock .....</b>                  | <b>18</b> |
| <b>13. Wireless Pairing.....</b>                  | <b>19</b> |
| <b>14. Check Message .....</b>                    | <b>20</b> |

# 1. Precautions

 Please be informed that we're not responsible for any incident or mishap caused by partial modification of this product. To avoid such situation, customers need to contact our customer service team or system installation staff in advance, and any modification should be conducted under our surveillance.

- Do not connect incompatible adaptor.
  - Use only adaptor approved by CAS for use with this particular model.
  - The use of any other types may invalidate any approval or warranty, and may be dangerous.
  - For availability of approved enhancements, please check with your dealer.
- Don't install the **CRD-F** series in direct sunlight.
- Avoid sudden temperature changes, vibration, wind, water or dirt.
- Avoid from the shock of excessive weight.
- Place the scale away from water.
- Use away from heavy R.F noise.
- Do not disassemble or modify this product.

# 2. Main Features

- Water proof: IP65
- ZigBee wireless communication
- Interface with crane scale & wheel load scale & indicator
- Standard remote control
- Tilt and swivel mount bracket
- Touch key


### 3. Technical Specifications

#### ◆ General specifications


|                   |   |
|-------------------|---|
| Display           | 2300F: FND (2.3 inch) / 3000F: FND (3 inch)                   |
| Display lamp      | Zero, Tare, Hold, Stable, Power                               |
| Touch key         | Zero, Tare, Hold, Power                                       |
| Case material     | Engineering plastic   |
| Temperature range | -20℃ ~ 60℃  |
| Product weight    | 2300F: Approx. 1.5kg / 3000F: Approx. 2.2kg                   |
| Adaptor           | 12V $\overline{\text{---}}$ 1A                                |
| Option 1 (OP-01)  | RS232C, RTC(Real time clock), 2solid state relays and 4inputs |
| Option 2 (OP-02)  | Use the vehicle power (12~24V $\overline{\text{---}}$ )       |

#### ◆ Product size

##### 1) CRD-2300F



##### 2) CRD-3000F





## 4. Description of Panels and Symbols



| DISPLAY    |   |
|------------|---|
| 00000      | Displays weight or messages                         |
| ○          | Indicates that the weight to be in stable condition |
| ZERO lamp  | Indicates that scale is stable and at zero          |
| Kg/lb lamp | Unit conversion operating lamp                      |
| TARE lamp  | Indicates that scale is currently using a tare      |
| Power lamp | Power lamp  |
| kg lb      | Indicates the weighing unit                         |

| KEYBOARD |  |
|----------|--|
|          | Turn on and off the product                  |
|          | Return the display to zero                   |
|          | Used to change unit                          |
|          | Used to weigh an item by using the container |

## 5. Installation




|     |                             |
|-----|-----------------------------|
| 12V | Power adaptor + (RED)       |
| GND | Power adaptor – (BLACK)     |
| TX3 | Not used (Extra RS232C TXD) |
| RX3 | Not used (Extra RS232C RXD) |
| GND | Not used (Extra RS232C GND) |

|     |                    |
|-----|--------------------|
| RX1 | Not used           |
| GND |                    |
| TX2 | RS232C TXD (OP-01) |
| RX2 | RS232C RXD (OP-01) |
| GND | RS232C GND (OP-01) |


|       |   |
|-------|---|
| EX+   | Not used  |
| EX-   |   |
| SIG+  |   |
| SIG-  |   |
| GNG   |   |
| POWER | External key 4 contact / 4inputs (OP-01)<br><b>i</b> "HOLD" mark is the same as "kg/lb" |
| ZERO  |   |
| TARE  |   |
| HOLD  |   |
| GND   |   |
| EVCC+ | 2 solid state relays contact (OP-01)  |
| OUT1  |   |
| EVCC+ |   |
| OUT2  |   |

## 1) External input circuit



- External inputs are interlocked with the touch keys.

## 2) Solid state relay circuit



- Maximum load (AC, DC 350V /130mA)

- Output conditions

| Output               | Conditions                              |
|----------------------|---|
| OUT2 ON (low limit)  | Low limit < Measured value ≤ High limit |
| OUT1 ON (high limit) | High limit < Measured value             |
| OUT1,2 OFF           | Measured value ≤ Low limit              |

## 6. General Function

### 6.1. Zero function

Use to correct drifted zero value when the scale is unloaded, and motion is not detected. This function works when ZERO KEY is pressed, and the ZERO LAMP is on.

### 6.2. Setting Tare Weight Function

Press the TARE KEY. Then, the scale will memorize the weight of the tare and will display zero value "0"kg. The TARE LAMP will be on.

To escape this function, remove everything from the scale, and press the TARE KEY. Then, the TARE LAMP will be off and this function is terminated.

### 6.3. Hold Function

**i** This function will only work with IR remote control.

**i** Also, F08 of CCB setting mode must be set to 4.

#### ■ Automatic hold

- Press \* KEY when the scale is empty (Initial zero state).
- The weight display will indicate **H h 0 0**. HOLD LAMP is on.
- After loading a thing, if the weight turns stable then, a display shows - - - - - and average weight will appear.
- The weight of a loaded thing is displayed.
- To escape the automatic hold mode, when zero point is on, press \* KEY. Then, the message of **H h 0 F F** is displayed and HOLD LAMP is off and normal weighing mode is reverted.

#### ■ Manual hold

- Press \* KEY loading a thing.
- This message of **H 0 L d** is displayed and sequentially the message of - - - - - is shown with appearing the average weight.
- The weight of a loaded thing is displayed.
- To escape the manual hold mode, remove everything from a hook, or press the \* KEY. Then, HOLD LAMP will be off and the scale changes from a hold mode to a normal mode.

## 7. Test Mode

### (1) How to enter this mode

Press the **ON KEY** to power on and immediately press **ZERO KEY** to enter test mode.

### (2) Testing Menu (TEST 1- TEST 2)

#### ■ TEST 1 : Keyboard Test

| Key | Remote Control | Display | Description  |
|-----|----------------|---------|--|
|     |                |         | Press a keyboard that you want to test, and then the display message will be shown. If press a TARE KEY, move on TEST 2. |
|     |                |         |  |
|     |                |         |  |
|     |                |         |  |
|     |                |         |  |

#### ■ TEST 2 : Display Test

| Display | Description   |
|---------|---|
|         | TEST 2 runs off automatically and a display is on. If press the TARE KEY, move on normal mode |

## 8. Setting Mode

### 8.1. How to enter this mode

Press the ON KEY to power on and immediately press TARE KEY.  
And press the TARE KEY again.

### 8.2. Keyboard

- : Use to set up an initial zero value (0).  
(F12, F13: Used to move the input value to the left or right by one place)
- : Use to add a value of "1" from existing value.
- : Use to save an inputting value and to move on next menu.

### 8.3. Menus

- F01: PC / Printer connection (0~2)

| Setting Menu | Description       |
|--------------|-------------------|
| F01-0        | Wireless          |
| F01-1        | RS232C            |
| F01-2        | Wireless & RS232C |

- i** In case of F01-0/2, you used the CRC-200 (Wireless dongle)
- i** Weighing data will be sent by according to set in F02.

- F02: Function \* key (Remote controller) (0~2)

| Setting Menu | Description                                   |
|--------------|---|
| F02-0        | Operation is equal to the * key of the master |
| F02-1        | Send data command key (Print format)          |
| F02-2        | Send data command key (22bytes format)        |

- F03: Item number (Identification number of each item) (0~9)

| Setting Menu | Description |
|--------------|-------------|
| F03-0        | Item No.0   |
| F03-5        | Item No.5   |
| F03-9        | Item No.9   |

■ F04: Print line feed (0~9)

| Setting Menu | Description  |
|--------------|--------------|
| F04-0        | 1 line feed  |
| F04-5        | 6 line feed  |
| F04-9        | 10 line feed |

■ F05: Print form (0,1)

| Setting Menu | Description                           |
|--------------|---------------------------------------|
| F05-0        | Form 0 (weigh No., Item No., weight)  |
| F05-1        | Form 1 (Serial No., Item No., weight) |

**i** When the F02-1 is selected, this form is printed.

**i** The weigh No. is not saved.

[FORM 0]

|                                      |
|--------------------------------------|
| 2014.10.13 12:00<br>001, ID_9, 25 lb |
|--------------------------------------|

[FORM 1]

|  |
|--|
| 2014.10.13 12:00<br>SN_02, ID_9, 25 lb |
|--|

■ F06: Initialization of serial number (0,1)

| Setting Menu | Description                         |
|--------------|-------------------------------------|
| F06-0        | Maintain current number             |
| F06-1        | Initialization (starting from No.1) |

■ F07: Auto transmit at stable (0~2)

| Setting Menu | Description                          |
|--------------|--------------------------------------|
| F07-0        | Not used                             |
| F07-1        | Send data at stable (Print format)   |
| F07-2        | Send data at stable (22bytes format) |

■ F08: Auto transmit at data hold (0,1)

| Setting Menu | Description |
|--------------|-------------|
| F08-0        | Not used    |
| F08-1        | used        |

**i** The hold data will be sent by according to set in F07.

- F09: Wireless connection of other company's product (0~2)

| Setting Menu | Description                        |
|--------------|------------------------------------|
| F09-0        | Not used                           |
| F09-1        | Product with 22bytes RS232C format |
| F09-2        | Product with 18bytes RS232C format |

- i If you select F09-1 or F09-2, you must use the CRC-200 dongle at the scale.

- F10: RS232C Stream mode (0,1)

| Setting Menu | Description |
|--------------|-------------|
| F10-0        | Not used    |
| F10-1        | Stream mode |

- F11: High limit (not included weighing points)

| Setting Menu | Description                            |
|--------------|--|
| 200          | 20.0 lb (In case of one decimal point) |

- F12: Low limit (not included weighing points)

| Setting Menu | Description                            |
|--------------|--|
| 100          | 10.0 lb (In case of one decimal point) |

## 9. Infrared Remote Controller

### 9.1. How to use



-  : Use to power on/off the CRD-F series
-  : Same as keyboard of CRD-F series
-  : Same as keyboard of CRD-F series
-  : Same as keyboard of CRD-F series
-  : Same as keyboard of CCB crane scale
-  : Used to add weights.

If press a **SUM KEY**, the sum of weights is displayed.  
 After that, about 2 sec later, a weighing mode is reverted.  
 Weight of less than 5 digits is not summed.  
 Maximum of sum weights is 99999, and if it exceeds the weights is initialized to zero.

### 9.2. Specification

| List               | Description       |
|--------------------|-------------------|
| Available Distance | 6 m ~ 10 m        |
| Available Angle    | 60°               |
| Power              | 3V (1.5V AA 2 EA) |

## 10. Wireless Specification

|                            |                           |
|----------------------------|---------------------------|
| RF frequency range         | 2400 ~ 2483.5 MHz         |
| Output power               | Max. 4dBm                 |
| Channel width              | 2 MHz                     |
| Frequency offset           | < ±30ppm                  |
| Transmit data rate         | 250Kbps,500Kbps           |
| Receiver sensitivity       | -99dBm (PER <1%)          |
| Maximum input level        | 0dBm                      |
| RF In/out impedance        | 50 ohm (TXRF, RXRF)       |
| Spurious(2nd harmonics)    | < -30dBm                  |
| Radio link effective range | Approx. 100M (Open space) |

# 11. RS-232C Interface

- 1) Type : EIA-RS-232C
- 2) Method : Full-duplex, asynchronous transmission Format

- ① Baud rate: 9600 bps
- ② Data bit: 8 bits
- ③ Code : ASCII

### 3) Format (22bytes)



|             |   |                                    |      |      |      |      |      |      |
|-------------|---|------------------------------------|------|------|------|------|------|------|
| Header 1    | ST  | Stable weight data (0x53) (0x54)   |      |      |      |      |      |      |
|             | US  | Unstable weight data (0x55) (0x53) |      |      |      |      |      |      |
|             | OL  | Overload (0x4F) (0x4C)             |      |      |      |      |      |      |
|             | HD  | Hold weight data (0x48) (0x44)     |      |      |      |      |      |      |
| Header 2    | GS  | Gross data (0x47) (0x53)           |      |      |      |      |      |      |
|             | NT  | Net data (0x4E) (0x54)             |      |      |      |      |      |      |
| ID          | Command address ID is selected in F02 (If ID is 1, 0x31 is sent)  |                                    |      |      |      |      |      |      |
| Lamp status | Bit7  | Bit6                               | Bit5 | Bit4 | Bit3 | Bit2 | Bit1 | Bit0 |
|             | 1   | Stable                             | 1    | Hold | 1    | Net  | Tare | Zero |
| Data        | Example 1) 13.5 lb ' ', ' ', ' ', ' ', '1', '3', ' ', '5'<br>Example 2) 135 lb ' ', ' ', ' ', ' ', '1', '3', '5', ' '<br>Example 3) -13.5 lb '-', ' ', ' ', ' ', '1', '3', '5', ' ' |                                    |      |      |      |      |      |      |
| Unit        | Kg  | (0x6B) (0x67)                      |      |      |      |      |      |      |
|             | g   | (0x20) (0x67)                      |      |      |      |      |      |      |
|             | lb  | (0x6C) (0x62)                      |      |      |      |      |      |      |
| Terminator  | C <sub>R</sub> L <sub>F</sub>   | (0x0D) (0x0A)                      |      |      |      |      |      |      |

## 12. Real Time Clock

### 1) How to enter this mode

Press the ON KEY to power on and immediately press kg/lb KEY.  
And press the TARE KEY.

### 2) Keyboard



: Used to increase the setting constant one by one.



: Used to move the input value to the left or right by one place.



: Used to save the value and to move next menu.

| Display | Description  |
|---------|--|
| YEAR    | Year input readiness.  |
| 20 14   | Modify the year by pressing the numerical keys and press <b>TARE KEY</b> |
| DATE    | Month & date input readiness.  |
| 10 13   | Modify the date by pressing the numerical keys and press <b>TARE KEY</b> |
| TIME    | Time input readiness.  |
| 18 00   | Modify the time by pressing the numerical keys and press <b>TARE KEY</b> |
| End     | The end  |

## 13. Wireless Pairing

| Step | Operation & Description   |
|------|---|
| 1    | <p><i>How to enter the pairing mode</i></p> <p><b>1) CCB crane scale</b><br/>           When the display is off, press ON/OFF key while pressing * key.<br/>           When “E=40 F”(Firmware version) is displayed, press kg/lb key.<br/>           Then, “r F 5 E E” is displayed.</p> <p><b>2) CRD-F wireless display</b><br/>           Press the ON/OFF key to power on and immediately press kg/lb key.<br/>           And press the kg/lb key again.<br/>           Then, “r F 5 E E” is displayed.</p> <p><b>3) CRC-100 controller</b><br/>           When the display is off, press ON/OFF key while pressing ENTER key.<br/>           When “E=50 F”(Firmware version) is displayed, press3 key.<br/>           Then, “r F 5 E E” is displayed.</p> <p><b>4) CRC-200 wireless dongle</b><br/>           Press the SET KEY for the 5 seconds with the power on that connected.<br/>           Then, the green light is blinking.</p> |
| 2    | <p><i>Pairing</i></p> <p>When “r F 5 E E” is displayed at both products, if you press * key of CCB crane scale, pairing will finish.</p> <p> Please check “E n d” message at both products.<br/>           If ending message is not appear, please repeat the pairing.</p>   |

## 14. Check Message



When a thing is over-weighed within the maximum weight value, the error message is displayed.

Do not weigh the thing whose the limit of a maximum weight value is exceeded.

If a load cell is broken, then the load cell has to be replaced.



Something wrong in a Load cell connection or in an A/D conversion.

Please contact us to resolve this technical problem.



When the scale and CRD-F series does not communicate, this is displayed.

Confirm radio link effective range.

# MEMO



# MEMO

# CRD -2300F/3000F

Wireless Remote Display



CAS BLDG., #1315, YANGJAE-DAERO,  
GANGDONG-GU, SEOUL, KOREA

TEL\_ 82 2 2225 3500

FAX\_ 82 2 475 4668

[www.globalcas.com](http://www.globalcas.com)